


DASHBOARD AND CONSOLE

DASHBOARD DISASSEMBLY/ASSEMBLY

- 1. Disassemble in the order indicated in the table.
- 2. Assemble in the reverse order of disassembly.



1	Defroster nozzle
2	Side demister nozzle
3	Center duct

4	Duct
5	Dashboard crash pad