


STARTING SYSTEM (WL, WL Turbo) / CHARGING SYSTEM (WL, WL Turbo)


Z WIRING DIAGRAM



A1-01 STARTER(E)



A1-02 GENERATOR(E)



HARNESS SYMBOL :  (F)  (E)  (R)

